



## **“Keep ME Warm” Tools Needed for Installation**

**Teams will need the following tools for installation of the “Keep ME Warm” weatherization kits.**

1. A LADDER to reach outside windows for installing weatherization plastic.
2. An adjustable WRENCH to install the faucet aerators and showerhead.
3. A HAMMER to apply wooden lathe and plastic to outside of windows.
4. SMALL WOOD SAW to cut lathe.
5. BOX CUTTERS or SCISSORS to cut and size the weatherization plastic and weatherization tape strips.
6. SCREW DRIVERS to install gaskets.